

# Royal Signet Model

## Shroud Installation Instruction Sheet

1. FASTEN REAR SHROUD WITH SELF TAP SCREWS ON FRONT HOLES.
2. LAY 1" WIDE MASKING TAPE OVER HOOK VELCRO MOUNTED TO BASE PLATE SIDE PLATES, LEAVE MASKING TAPE HANGING DOWN EXPOSED, TO ALLOW REMOVAL AFTER SHROUD IS ALIGNED. (ANOTHER OPTION: LAY THIN 2" X 12" OR SO PLASTIC, CARDBOARD OR WOOD ALONG THE SIDE PLATES BETWEEN HOOK AND LOOP VELCRO UNTIL FRONT SHROUD IS ALIGNED, SLIDING THEM OUT BEFORE MOUNTING SHROUD WITH SCREWS).
3. MOUNT FRONT SHROUD OVER BASE PLATE ASSEMBLY ALIGNING REAR MOUNTING HOLES, INSTALL SHOULDER WASHERS INTO HOLES FROM INSIDE WALL OF FRONT SHROUD.
4. INSERT HEX MACHINE SCREW INTO SHOULDER WASHER HOLE AND TAP HOLE ON BASE PLATE.

