

## Bulb replacement and cleaning of the light

- Turn the light off and allow it to cool before removing the shield! Failure to do so can cause injury by burning!
1. Remove the shield by squeezing the ends towards each other gently and pulling forward.
  2. Remove the bulb by wrapping it in a tissue and gently pulling forward. Take care to avoid touching the bulb glass as it may shorten bulb life.
  3. Use only denatured alcohol to clean the glass reflector or the bulb!
  4. Use only mild detergent and water to clean the shield!
  5. Using a solution of mild detergent and water or typical commercial cleaner that does not include alcohol can clean the painted surfaces of the light.
  6. The bulb can be replaced by gently pushing the contact pins back into the lamp socket.
  7. Replace the shield by gently squeezing the sides of the shield and gently pushing it into the housing. You will hear a definite “pop” when the shield seats properly.  
**Failure to properly seat the shield could cause it to fall off and cause injury!**
  8. Turn on the light and check the focus by shining the light on a surface approximately 28” away. The pattern should be even with defined edges over an area of 3 \_” x 6 \_”.
  9. If necessary, rotate the adjusting screw at the back of the head until an even, sharp pattern is achieved.

